


SOLUS CLAMP Installation Instructions


1)

SINGLE MOUNT FIXING



PUSH 2 X M12 SET SCREWS INTO HEX RECESS.

DOUBLE MOUNT FIXING



PLACE THE CLAMP ON THE STRUCTURE.

2)



PLACE CLAMP ONTO STRUCTURE AND TIGHTEN THE CENTRAL M12 FIXING TO A **TORQUE OF 10N.m.**



PLACE CLAMP ONTO STRUCTURE AND ATTACH THE NUTS TO THE BOLTS FINGER TIGHT.

3)




LAY THE CABLE INTO THE CLAMP. TAKE CARE TO NOT DAMAGE THE CABLE.




LAY THE CABLE INTO THE CLAMP. TAKE CARE TO NOT DAMAGE THE CABLE.

4)




FASTEN NUTS ONTO THE BOLTS AND TIGHTEN TO A **TORQUE OF 10N.m.** TAKE CARE TO TIGHTEN EACH SIDE AT AN EQUAL RATE.




REMOVE THE NUTS ON THE BASE AND RE-FASTEN NUTS ONTO THE TOP CLAMP BOLTS AND TIGHTEN TO A **TORQUE OF 10N.m.** TAKE CARE TO TIGHTEN EACH SIDE AT AN EQUAL RATE.

LINER OPTIONS



FOLLOW PREVIOUS INSTALL STEPS BUT ENSURE THE LINER IS PLACED WITHIN THE BASE CLAMP PRIOR TO CABLE LAYING.


STACKING OPTIONS



FOLLOW INSTALLATION STEPS 1 TO 3. FOR STEP 4 ENSURE THE NUTS ARE ORIENTATED WITH THE FLAT SIDE OF THE NUT PARALLEL WITH THE SIDES OF THE CLAMP (AS SHOWN)



PLACE THE BASE OF A SECOND CLAMP ONTO THE TOP OF THE INSTALLED CLAMP. ENSURE THE NUTS ARE PUSHED INTO THE HEX RECESS IN THE BASE OF THE CLAMP.



INSTALL THE TOP CLAMP IN ACCORDANCE WITH STEPS 3 AND 4.

SOLUS INSTALLATION INSTRUCTIONS - ISSUE 01